



Instruction

After having created the update CD, please do the following:

1. Switch on the player.
2. Open the disc tray.
3. Insert the update CD you have created.
4. Close the disc tray.
5. If you are asked for, follow the instructions displayed on the screen.
6. The disc tray will open during the upgrade. Please remove the update CD.
- 7. IMPORTANT: the update process has not yet finished, do not switch off the device and do not close the disc tray!**
8. The disc tray will close automatically at the end of the update after 3 to 4 minutes. The player is also switched off automatically.
9. Now switch the device on again.
10. Enter the OSD menu by pressing the button 'Setup' and choose the menu 'General' with the direction button. Then, press 'Enter'.
11. Now check the firmware version which you can find in the last line. The last two figures stand for the version.
12. Highlight the menu point 'Factory default' by means of the direction buttons and press 'Enter'.
13. The player is now ready for operation.

